



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

DW Chorus 24 Parts List

Item	Description
5010000006	24vDC 0.12A FAN FOR COLOUR CHORUS 24
5040000099	24V 16.7A POWER SUPPLY FOR COLOUR CHORUS 24, COLOUR CHORUS 72,
5050100034	15 DEGREE LENS FOR COLOUR CHORUS 24, COLOUR CHORUS 48
5050100035	8 DEGREE LENS FOR COLOUR CHORUS 24, COLOUR CHORUS 48
6060400000	KSD301 250V 10A 90 DEGREES THERMOSTAT FOR COLOUR CHORUS 24, CO
7010200911A	SOI SUPPORTING FOOT FOR COLOUR CHORUS 24, DW CHORUS 48
7010200912A	SOI SIDE PLATE FOR COLOUR CHORUS 24
7010500698	SOI REAR PANEL FOR DW CHORUS 24
7020900001	SOI FAN GRILL FOR COLOUR CHORUS 24, FUZE WASH Z350, FUZE WASH Z:
7030100111A	SOI LENS HOLDER FOR COLOUR CHORUS 24
7030100112	SOI LENS BASE PLATE FOR COLOUR CHORUS 24
8010000961	LA20104-03A LED PCB FOR DW CHORUS 24
8010000966	LA2108-05A DMX PCB FOR COLOUR CHORUS 24, DW CHORUS 24
8010046700	LA2115-06B JUMPER PCB FOR COLOUR CHORUS 24, COLOUR CHORUS 72, C
8010046900	TEMPERATURE CONTROL PCB FOR COLOUR CHORUS 23 (LA4121-04A-001)
8010100388	SOI LAETM0-01A MAIN PCB FOR DW CHORUS 24
8010100389	LA2115-02A DISPLAY PCB FOR DW CHORUS 24
ESD0008-B	BLUE FEMALE RECEPTACLE FOR PZ720A, VBAR 270, PD-60, POWER SPOT 5
ESD0008-W	WHITE FEMALE RECEPTACLE FOR PZ720A, VBAR 270, PD-60, ELED B48,OP'
LA-WG-004	DISPLAY COVER FOR CUEPIX PANEL, CUEPIX STRIP TRI, CUEPIX STRIP, CU
LA2115-L-13	BRACKET ADJUSTER FOR COLOUR CHORUS 24
LARJ45-03A	LARJ45-03A RJ45 PCB FOR CUEPIX BATTEN, CUEPIX PAR 300, CUEPIX BLIN
LCD-3118	DISPLAY BUTTON FOR CUEPIX BLINDER WW4
P-CON CABLE 14G	14 GAUGE P-CON CABLE 14 AWG FOR M-4, ACL 360 MATRIX
P000000711	RIGHT BRACKET ASSEMBLY FOR COLOUR CHORUS 24,48 & 72